



# Air:bit

Android-app



# Setup



- Install Airbit.apk on your Android device
- Turn on bluetooth on device
- Copy the Wonderbit-Airbit-Androidapp.hex to the micro:bit on the drone (MICROBIT drive)
- Power on drone/micro:bit
- In app: Click “Choose micro:bit”
- Select the micro:bit device
- Change the phones angle and watch the micro:bit display center dot change on phone and drone
- Click Arm to start and stop propeller
- Use phone angles + Yaw and Throttle to steer drone
- Press “Menu” for data analysis and more

